

X-Cite speedDIAL 1.6.0 Update:

This updates speedDIAL with UV Mode for use with X-Cite XYLIS/mini+. No change will be noticed when speedDIAL is used with any other X-Cite light source.

1. Save the attached file “**SpeedDIAL 1.6.0 Update.zip**” to your computer.
2. Extract files into a folder on your desktop.
3. Connect X-Cite unit to your computer. Make sure speedDIAL is connected to unit and turn on. (If this is the first time you have connected a XYLIS/mini+ to the computer, install Windows driver.)
4. Run LX Firmware Updater executable.
5. Click start.
6. Select COM port for X-Cite unit and click on Connect.
7. Wait for updater to do erase and program sections. Progress bar will appear to stall at ~75% complete, it will be done at this point.
8. Power cycle X-Cite unit.
9. Go into service menu on speedDIAL and verify that SW2 is 1.6.0.