X-Cite® 120LED *Boost* Control Options

Control Options	
Manual Control – speedDIAL	ON/OFF Speed sensitive intensity control 1 favorite intensity setting Left and right-handed control option
USB	ON/OFF Intensity control Compatible with X-Cite 120LED, X-Cite 120PC and X-Cite *exacte* drivers
TTL	ON/OFF