
C30739ECERH Series Short Wavelength Enhanced Silicon Avalanche Photodiode



The C30739ECERH large area silicon avalanche photodiode (APD) is intended for use in a wide variety of broadband low light level applications covering the spectral range from below 400 to over 700nm.

The device is designed to have enhanced short wavelength responsivity with quantum efficiency typically exceeding 80% at 430nm. In addition, this large area APD is optimized for low noise and low capacitance (60pF). Operation at an avalanche gain of up to M = 400 at 430nm is feasible with a special high gain version.

The standard ceramic carrier package allows for easy handling and coupling to scintillating crystals such as LSO and BGO. Combined with the superior short wavelength responsivity, it makes this APD ideal in demanding high volume applications such as Positron Emission Tomography (PET).

While the devices are warranted over the entire specification, customers are welcome to discuss their custom requirements to accommodate special design, packaging or testing needs.

Key Features

- Large area silicon APD
- Short Wavelength enhanced responsivity
- High quantum efficiency (80%) at short wavelength(430nm)
- Easy coupling to scintillating crystals
- Non-magnetic package
- Custom packaging available
- Excellent timing resolution
- RoHS compliant

Applications

- Molecular imaging (PET)
- Nuclear medicine
- Fluorescence detection
- High energy physics
- Safety radiation detection
- Optical tomography
- Environmental monitoring



Table 1 – Package and Chip Dimensions

Parameter	Measurement	Unit		
Package Size	8.50 x 8.00 x 1.55	mm		
Chip size	6.65 x 6.65	mm		
Active area	5.6 x 5.6	mm		


Table 2 – Electrical Characteristics, at T_A = 22 °C; at typical dV


Symbol	Parameter	C30739ECERH (standard version)			C30739ECERH-2 (high gain version)					
		Min	Тур	Max	Min	Тур	Max	Unit	Conditions	
V _{op}	Operating Voltage	-	400	420	-	400	450	V		
dV	dV = V _{br} - V _{op}	-	15	-	-	10	-	V	defines relation of operating voltage V _{op} to breakdown voltage V _{br}	
М	Gain at V _{op}	80	100	-	180	200	-			
Q.E.	Quantum Efficiency	65	80	-	65	80	-	%	at 430 nm	
R	Responsivity	-	26	-	-	52	-	A/W	at 430 nm and Typical Gain M	
T_{coeff}	Temp. Coefficient for constant gain		1.2			1.2		V/°C		
CJ	Capacitance	-	60	-	-	60	-	рF	at V _{op}	
t _R	Rise Time	-	2	-	-	2	-	ns		
Ι _D	Dark Current	-	1.5	-	-	2	-	nA	at V _{op}	
I _N	Noise Current	-	0.3	-	-	0.4	-	pA/√Hz	at V _{op}	

Table 3 – Maximum ratings

Parameter	Min	Typical	Max	Unit
Operating Temperature	0	-	50	°C
Storage Temperature	-20	-	70	°C
Maximum Humidity (non-condensing)	-	-	60	%

C30739ECERH Series Short Wavelength Enhanced Silicon Avalanche Photodiode








Figure 1

Capacitance vs. operating voltage

Figure 2 Spectral Response vs. Wavelength



Electrical properties vs. bias voltage

C30739ECERH Series Short Wavelength Enhanced Silicon Avalanche Photodiode




Figure 4 Package Dimensions in mm

RoHS Compliance

The C30739ECERH Si APD is designed and built to be fully compliant with the European Union Directive 2011/65/EU – Restriction of the use of certain Hazardous Substances (RoHS) in Electrical and Electronic equipment.



Warranty

A standard 12-month warranty following shipment applies.

About Excelitas Technologies

Excelitas Technologies is a global technology leader focused on delivering innovative, customized solutions to meet the lighting, detection and other high-performance technology needs of OEM customers.

Excelitas has a long and rich history of serving our OEM customer base with optoelectronic sensors and modules for more than 45 years beginning with PerkinElmer, EG&G, and RCA. The constant throughout has been our innovation and commitment to delivering the highest quality solutions to our customers worldwide.

From aerospace and defense to analytical instrumentation, clinical diagnostics, medical, industrial, and safety and security applications, Excelitas Technologies is committed to enabling our customers' success in their specialty end-markets. Excelitas Technologies has approximately 3,000 employees in North America, Europe and Asia, serving customers across the world.

Excelitas Technologies 22001 Dumberry Road Vaudreuil-Dorion, Quebec Canada J7V 8P7 Telephone: (+1) 450 424 3300 Toll-free: (+1) 800 775 6786 Fax: (+1) 450 424 3345 detection@excelitas.com Excelitas Technologies GmbH & Co. KG Wenzel-Jaksch-Str. 31 D-65199 Wiesbaden Germany Telephone: (+49) 611 492 430 Fax: (+49) 611 492 165 detection.europe@excelitas.com Excelitas Technologies Singapore, Pte. Ltd. 8 Tractor Road Singapore 627969 Telephone: (+65) 6775 2022 (Main number) Telephone: (+65) 6770 4366 (Customer Service) Fax: (+65) 6778-1752 detection.asia@excelitas.com



For a complete listing of our global offices, visit www.excelitas.com/ContactUs

© 2014 Excelitas Technologies Corp. All rights reserved. The Excelitas logo and design are registered trademarks of Excelitas Technologies Corp. All other trademarks not owned by Excelitas Technologies or its subsidiaries that are depicted herein are the property of their respective owners. Excelitas reserves the right to change this document at any time without notice and disclaims liability for editorial, pictorial or typographical errors.