

Datasheet

High-power / short wavelength fiber delivery systems:

kineFLEX-HPV™ / kineFLEX-UV™

The kineFLEX-HPV™ and kineFLEX-UV™ are robust laser beam delivery systems from the kineFLEX® family of products.

This fiber delivery technology is designed around pre-focused and integrated optical assemblies. The fiber is designed to be mode-matched to your laser parameters to achieve transmission efficiencies greater than 65%.

Single-mode fiber enables the user to decouple the laser beam astigmatism and dynamic beam pointing instability from the measurement application. Fiber also provides a convenient packaging solution by relocating sources of heat and by removing bulk components thereby reducing the number of optical surfaces from the beam alignment scheme.

The kinematic design of the kineMATIX® coupler enables true 'Plug & Play' benefits for single mode and polarization-maintaining fiber designs. Sub-micron repeatability and sub-microradian stability mean systems can be aligned once only and are stable for multiple remove and insert operations, thus providing true modularity for instrument designs. Excelitas fiber systems can be customized for exacting OEM specifications. Outputs can be configured to produce

pure Gaussian profiles with extremely low wavefront error, as well as engineered spatial profiles and shapes. Single-mode fiber designs are also available for multi-wavelength, broadband transmission (>200nm bandwidth) and ultra-high vacuum compatibility.

Some of the product features include:

- High power fibers for singlewavelengths (405-640 nm)
- UV fibers 355 nm and 375 nm
- Guaranteed for performance up to high power levels of 500 mW for most wavelengths
- Highly insensitive to thermal effects
- Stable ruggedized platform for industrial applications
- Polarization-maintaining and single-mode transmission
- Custom OEM versions available
- Higher power and multiple wavelength versions on request



Technical Specifications

Fibers for	Operating Wavelengths (λ in nm)								Maximum input power (mW)
Single-λ UV laser	355	375							20
Single-λ high-power laser			405	445					200
					488	515	532	561	640
Broadband λ high-power laser			405 – 640						500 ¹
				488-640					500

Operating performance		Units
Polarization ratio	≤ -20	dB
Throughput efficiency ²	Single- λ high-power fibers: $\geq$ 65 Broad-band high-power fibers: ≥ 60	%
Fiber parameters		
Fiber length	1, 2, 3	m
Fiber protective jacket	Stainless steel, 5 mm OD	-
Collimated output beam		
Beam diameter	0.7	mm
M Squared	typ 1.1	-
Pointing stability	≤ 1	$\mu\text{rad}/^\circ\text{C}$
Mechanical dimensions	$\varnothing 12 \times 50$	mm
Beam position	≤ 0.15	mm
Beam angle relative to mechanical axis	≤ 0.5	mrad
Environmental conditions		
Storage temperature	10 to 50	$^\circ\text{C}$
Operating pressure	Atmospheric	-
Operating temperature	10 to 40	$^\circ\text{C}$
Operating humidity	Non-condensing	-

¹With maximum 200mW in the 405-460 nm range. Maximum combined power 500 mW.

²Assuming 0.7 circularized input beam waist diameter, and $M^2 < 1.2$.

OEM versions available on request.

For further information please contact:

Excelitas

Mitchell Point, Ensign Way, Hamble, Hampshire, UK, SO31 4RF

Email: ham.customerservice@excelitas.com

Tel: +44 (0) 23 80 744 500 | Fax: +44 (0) 23 80 744 501

www.excelitas.com